

# Lighthouse

## 12 LED Camping Lamp

(Product Code: L/H 12LEDCAMP)

### Instruction Manual

This manual will provide you with directions for the effective operation of the 12 LED Camping light.

#### IMPORTANT

It is essential that you read the instructions contained in this manual before using the Camping Lamp for the first time. Failure to follow these instructions could result in damage to the lamp. This manual should be stored safely for future reference.

Your new Lighthouse 12 LED Lamp is perfect for camping and for use around the home and garage. The 12 high power LED's provide a safe and portable source of light, for use just where and when you need it. Ideal for use during power failures, roadside emergencies or fishing trips.

#### Location of Controls

- 1) Folding Carry Handle
- 2) LED Lights
- 3) Adjustable Dimmer Knob
- 4) Battery Compartment \*

\* This product is operated using 4 x "D" batteries. To achieve the best performance from your Camping Lamp we recommend the use of Alkaline or high performance rechargeable batteries in this product. (Batteries Not Included).




Figure 2

#### Installing Batteries

1. Remove the bottom cover of the lamp by rotating it counter-clockwise.
2. Remove the battery holder from the inside of the lamp base.
3. Insert 4 x "D" size batteries by following the correct polarity markings shown on the battery holder.
4. Place the battery holder inside the base by matching up the flat edge inside the lamp base (As shown, Figure 2).
5. Close the bottom cover by rotating it clockwise once it is placed on the base.

#### Operating the LED Lamp

The LED Lamp features 12 super bright LED lights.

1. Simply turn the Adjustable Dimmer Knob clockwise to turn on the LED Lamp.
2. Adjust the brightness by turning the knob to your desired setting.

#### Safety Precautions

- If the lamp is not being used for long periods of time, please remove the batteries to prevent possible battery leakage.
- Avoid looking directly into the LED lights when it is ON, to prevent possible eye damage from occurring.
- Use only the size and type of batteries specified.
- Do not mix different types of batteries (e.g. Alkaline and Nicad).
- Carefully read this Instruction Manual before operating this unit.




Figure 1

#### Cleaning

All exterior surfaces of the Camping Lamp can be wiped clean with a soft cloth dampened with a soap and water solution. Do not immerse or submerge any part of Camping Lamp in water or any other solvent. Never use solvents or cleaning agents containing petroleum (petrol, kerosene, oil), paint thinner, turpentine, alcohol, or ammonia. Harsh materials like these can damage the surfaces.

#### Maintenance



Only qualified service personnel must perform repairs.

Do not open the exterior casing of the lamp, as there are no user serviceable parts inside. Opening or visible attempts to open or repair a Camping Lamp may void any guarantee and/or cause damage to the product or personal injury. LED bulbs will never wear out under normal conditions and do not need to be replaced.

#### One-Year Home Use Limited Guarantee

Lighthouse guarantees this product to the original purchaser for a period of ONE YEAR against any defects in material or workmanship but shall not cover damage caused by misuse, abuse, alteration, or accident. This product is intended for home use only and the guarantee will not cover the product used for commercial purposes.