

LIGHTHOUSE®

USER MANUAL L/H MT1100R LED MINI TORCH

BEFORE USING FOR THE FIRST TIME

These instructions contain information necessary for safe and effective operation of this product. This product has unique features and, even if you are familiar with similar products, it is necessary to read these instructions carefully to ensure you fully understand the product. Ensure all users of the product read and fully understand these instructions. Keep these instructions with the product for future reference.

OPERATING FUNCTIONS

The output functions are controlled by a sequential switch on the side of the torch:

- ▶ Press and release the on/off button once to switch the torch on and into the low output mode.
- ▶ Press the on/off button again to switch the torch into medium output mode.
- ▶ Press the on/off button again to switch the torch into high output mode.
- ▶ Pressing the on/off button again will turn the torch off.
- ▶ Pressing and holding the on/off button will switch the torch on and into turbo mode (1000 Lumens). This mode will only last 30 seconds before the torch will switch back to the previous mode.

NOTE

All modes are reset after 8 seconds.

RECHARGING

This torch can be recharged using the provided USB-A to USB-C cable.

When the battery capacity is higher than 30%, the button indicator light will illuminate green. When the battery capacity is lower than 30%, the indicator light will illuminate red.

- ▶ Ensure the battery is fully charged before using the torch for the first time. This should be a minimum of 2 hours.
- ▶ It is important for the torch to be charged every three months to maintain the optimum condition of the battery.
- ▶ While on charge, the indicator light will flash red. This indicator light will illuminate solid green once the torch is fully charged.

The charging cable included with this product is for recharging the battery only. It cannot be used to directly power the torch.

USING THE CHARGING LEAD

Plug the USB charger lead into the micro USB charging socket on the side of the torch. Plug the other end of the lead into any suitable USB charging outlet.

PLEASE NOTE THE FOLLOWING

For the best performance results, Lithium-Ion batteries should not be stored for prolonged periods of time without being charged at regular intervals. Self discharge rate is approximately 10% per month. It is recommended the torch is stored in a higher charged state, in a cool, dry environment, away from direct sunlight.

It is important to note that when charging the torch, it should not be used and should be kept away from children and pets.

SAFETY

- ▶ Do not use if any of the components are damaged. If there is any doubt about the condition of the torch or charging cable, do not use.
- ▶ Never attempt to modify or repair this product. Repairs carried out by unskilled people can lead to damage to the product. Please contact the manufacturer, relevant service agent or similar qualified person to avoid any hazard.
- ▶ Do not cover the light when in use.
- ▶ Never leave the light unattended while charging.
- ▶ Do not shine the light in yours, other peoples or animals eyes.

TECHNICAL DATA

BATTERY TYPE	700mAh Lithium-Ion (16340)
BULB TYPE	LED
BRIGHTNESS	25 / 250 / 500 / 1000 Lumens
RUN TIME	10.5 Hrs / 4.5 Hrs / 2 Hrs / 30s
BEAM DISTANCE	110 Metres
CHARGE TIME	1.5 Hrs (Approx.)
IMPACT RESISTANT	Up to 1 Metre
WATER RESISTANT	IPX4
WEIGHT / SIZE	100g / 30 x 30 x 73mm
SUPPLIED WITH	300mm USB-C Charging Lead

INTENDED USE

For illuminating indoor and outdoor areas.

This torch must ONLY be used for it's intended purpose. Any other than those mentioned in these instructions will be considered a case of misuse. The user, and not the manufacturer, shall be liable for any damage or injury resulting from such cases of misuse. The manufacturer shall not be liable for any modifications made to the product, nor for any damage resulting from such modifications.

CLEANING & STORAGE

Clean the torch with a soft dry cloth when not in use. The torch should be stored carefully in a dry place out of reach of children.

DISPOSAL

Always adhere to national regulations when disposing of electrical goods that are no longer functional are are not viable for repair. Do not dispose of this product in the household waste bin, instead, check your local waste disposal authority for the correct method of disposing of any electrical or electronic equipment (WEEE).

GUARANTEE

Rechargeable battery life depends on many factors and the cells can become easily damaged, dependent on environmental and storage conditions. Your product is guaranteed from defect for a period of **1 year**, this excludes the battery which is covered for 90 days from the date of purchase, if you notice the running or charge times decreasing this is normal over the lifetime of the battery and is classed as fair wear and tear.

There will be some items within our range which will be non-serviceable but, in most cases we can supply replacement batteries for our products.

 **LIGHTHOUSE TORCHES**
Long Reach, Galleon Boulevard, Crossways Business Park, Dartford, Kent, DA2 6QE, UK

QFF DISTRIBUTION
24 Magna Drive, Magna Business Park, Citywest Road, Dublin 24, D24 FNYO, Ireland.

 www.lighthouse-torches.com

